



TP-Link Wireless N Mini Pocket Router (3.23.18)

1. Plugged the tplink into a router (Cat5 cable) and power. Wait for a solid green light on the tplink
 - a. On your computer which is connected to your router, click on internet icon which is in the task bar. It will display available networks
 - b. Click on TPLINK network
 - c. Input tplink password (included in the documentation for tplink). It will say connected.
 - d. Open a browser and type in <http://tplinklogin.net> and enter username and password:
 - i. Username is: admin
 - ii. Password is: admin
 - e. Click radio button for 'client'
 - f. Click on 'Save' on lower right of screen
 - g. It will ask you to connect to your wireless network (This is the company network)
 - i. Select the companies network (SSID)
 - ii. Enter password for the companies network
 - h. After the tplink reboots.
 - i. Unplug the tplink from the router and power
 - ii. Plug tplink into power near the TV2 and wait for solid green light
 - iii. Plug TV2 into tplink with Cat5 cable (make sure the lights on the TV2 under the Cat5 connector show solid green and blinking yellow.
 - iv. When the X on the network icon on the TV2 (lower left) goes away
 1. Go to the network menu on the TV2 and record the IP address
 2. On your computer install and open TView
 3. Add the IP address for the TV2 in the setup menu.

You are done